



When installing a ButterflyMX panel at a building without an access control system, the ButterflyMX needs to be wired directly to a Maglock. This requires the introduction of an isolation relay and a 12vdc adapter.

Isolation Relay:
Altronix RB5 Isolation Relay

Power Adapter for Relay:
AC to DC Adapter

Diode: 1N4004 1 AMP 400 VOLT