



Keypad Troubleshooting Guide





Does it light up?

(Give it a full minute to boot)

Yes

No



Does a PoE tester (or a known-good PoE device) indicate that 37- 57V reaches the Keypad location?

Yes

No



Installer must investigate power distribution.

Possible failure points:

- Physical cable
- POE injector/switch/router
- Network connection

Back to Start



Installer must investigate power distribution.

Possible failure points:

- Physical cable
- POE injector/switch/router

Back to Start



Keypad is receiving power.

Is it persistently flashing red?

Yes

No



Keypad is receiving power.

Next



Is it flashing yellow for more than 2 minutes?

Yes

No



Is it lit up solid white?

Yes

No



Press any key, does it respond by flashing/audio feedback?

Yes

No



Installer must contact Support.

E: support@butterflymx.com

P: (517) 480-6579 ext 2

Mon-Fri 6am-10pm EST



Device Working As Expected

Installer must contact Support.

E: support@butterflymx.com

P: (517) 480-6579 ext 2

Mon-Fri 6am-10pm EST

[Back to Start](#)



It's offline.

Installer must test the network -- connect a known-good device (e.g., laptop or "golden keypad").

Does the known-good device get an internet connection?

Yes

No

Installer must investigate network. Possible issues:

Physical
cabling fault?

POE
injector/switch/router
failure?

Network
issue?

Back to Start

Installer must contact Support.

E: support@butterflymx.com

P: (517) 480-6579 ext 2

Mon-Fri 6am-10pm EST

Installer must contact Support.

E: support@butterflymx.com

P: (517) 480-6579 ext 2

Mon-Fri 6am-10pm EST

[Back to Start](#)

Installer must contact Support.

E: support@butterflymx.com

P: (517) 480-6579 ext 2

Mon-Fri 6am-10pm EST

[Back to Start](#)