

Touchscreen Packing Sheet & Installation Guide For Outdoor Intercom

INST-Panel-Installation-Guide-v14-2020-05-29-US-EN

SUPPORT:

P: (571) 480-6579 ext. 2 (Mon-Fri, 6am-10pm EST)

E: support@butterflymx.com

PLEASE READ THE FOLLOWING BEFORE INSTALLING

Guidelines Step-by-Step Instructions 1. Record Serial Number located on back of 1. NO AC POWER panel 2. Confirm network communication from mount point to main headend 2. Ensure wiring min. specs are met: a. Power: 18/2 awg <50". Must be 3. For retrofit installations, check existing power conditioned by UPS. wiring for the network and power. b. Internet: CAT5e/6 < 300' to 4. BMX provides the following: router/switch. c. REX: Terminate to access control • Smart Intercom system OR introduce isolation relay Latch key for intercom • 24 VDC transformer with 12vdc adapter to wire to electric strikes. 5. BMX does not provide: 3. Secure the panel by locking the key latch. • Cat cable • Rex line 4. Call ButterflyMX support and provide serial UPS device number • Extension cable for power Isolation relay • 12 VDC adapter for isolation relay • Diodes (DC locks) Resistors (AC locks) 6. Provide room behind the mounting location for excess wiring 7. Never introduce two power sources for lock release in parallel 8. Recessed installations require proper silicone sealant



Touchscreen Packing Sheet & Installation Guide For Outdoor Intercom

INST-Panel-Installation-Guide-v14-2020-05-29-US-EN

SUPPORT:

P: (571) 480-6579 ext. 2 (Mon-Fri, 6am-10pm EST)

E: support@butterflymx.com



Power Supply

AC to DC transformer Input: 100-240V AC (mains) Output: 90 watts / 24V

Locking barrel connector

Uninterrupted Power Supply (UPS)

Minimum specs: 600VA / 300W





Power Cable

USA: NEMA 5-15 (typical 3-prong male)

IEC320-C13 (to power supply)

EU: [not shown]

CEE 7/4, Type F ("Schuko plug") IEC320-C5 (to power supply)



Panel Keys (2)

Installation:

- 1. Connect Ethernet to just ONE of the available ports
- 2. Connect the panel's relays to the building's door strike and/or access control system
- 3. Connect Panel > Power Supply > UPS > Wall Outlet

The Panel will start up like a computer. After loading, you should see the ButterflyMX software.

Test Relays:

- 5. Select "DOOR PIN" in the ButterflyMX software
- 6. When asked for apartment number, enter "01"
- 7. For PIN, enter "1234"

If successful, you will hear a chime from the panel and a click from the relays. The door strike (or other connected system) should respond.

Do not leave without calling support!

8. Call the ButterflyMX Support team, who will remotely set up the panel for this specific property.